

*ALL EXTERNAL PIPING MUST BE INDEPENDENTLY SUPPORTED. *ONLY BASE FITTINGS TO BE LEFT INSTALLED AT TIME OF SHIPMENT PER SII PROCEDURE. *Consult Snyder's Guidelines for Use and Installation prior to delivery. Available on-line at http://www.snyderindustriestanks.com/Technical ALL DIMENSIONS ARE IN INCHES, NOMINAL, & SUBJECT TO CHANGE WITHOUT NOTICE. ALL DIMENSIONS ON ROTATIONAL MOLDED PARTS ARE SUBJECT TO A ± 3% TOLERANCE.

